

From Mars Gaming team:

we want to thank you for the purchase of this product!

We try to improve everyday to offer the best service and the best quality on our peripherals. Thank you for your trust!

ARE YOU HAPPY WITH YOUR PURCHASE?

YES



Rate us in your marketplace and share your experience in your social media



@MarsGaming_



marsgaming



MarsGamingOfficial

NO



Please contact our technical support service by sending an e-mail to



support@marsgaming.eu

MSBAX

USER MANUAL

Note to user: Please read this manual before using your speaker and keep this sheet for future reference

A. Buttons:

(⏮): Tap to Play-Pause / Press the button for 2 seconds to switch ON-OFF

(M): Switch between the different modes: Bluetooth, USB, MicroSD, Radio FM...

(-): Play previous song / Press and hold to reduce volume

(+): Play next song / Press and hold to increase volume

(☼): Tap to change the lighting effect / Press the button for 2 seconds to switch lights OFF.

B. Battery charge:

Follow these steps to charge your MSBAX:

1. Connect the speaker to your PC. RED light will show while charging.
2. When the light is off, MSBAX is fully charged.


Note: Play time may vary by volume, audio content and lighting effect.

C. Bluetooth Mode:

Once the Bluetooth Mode is activated MSBAX can be connected to the Bluetooth devices successfully. Follow these steps to connect your phone/tablet via bluetooth:

1. Start the Bluetooth mode on your phone/tablet and tap "search device". Your phone/tablet will begin to search for Bluetooth devices.
2. The phone/tablet will display "MSBAX" on its Bluetooth devices list. Tap on it to connect.
3. Play the audio file you want to listen.

D. Radio FM:

1. Connect USB power cable to the speaker to improve radio signal reception.
2. Tap  button to start auto frequency scan and wait until scan process has finished.
3. Use – and + buttons to navigate through the scanned frequencies.

E. Pendrive & MicroSD card

Plug the pendrive or microSD card with .MP3 files into the port. The speaker will play the files automatically.

FREQUENTLY ASKED QUESTIONS

QUESTIONS & SOLUTIONS

Unsuccessful connection

1. Make sure the speaker is in Bluetooth mode
2. Make sure the speaker is not connected to another device.
3. Check if there are too many Bluetooth devices working in the area, it can interfere its connection.
4. Try to restart the Bluetooth of your device and reconnect to the speaker again.

No sound / Sound distortion

1. Check the volume of the phone and the speaker to adjust it
2. Check if the battery is low and recharge it if necessary.

Stuttering music

1. Check if the device is too far from the Bluetooth device
2. Check if there is any obstacle between the speaker and the device.

Speaker doesn't switch ON

1. Battery is low
2. Recharge it and reboot the speaker

PRECAUTIONS

1. Please store the product in a room temperature environment
2. Do not expose the product in rain or wet conditions
3. Do not drop the product
4. Do not disassemble or repair the product by yourself. Any disassembly or reparation will invalidate the warranty
5. Please use the correct voltage when charging the speaker
6. Don't use the speaker in high volume for a long time: it may cause hearing damage

*Please, keep this sheet for future references.
Visit www.marsgaming.eu for more info about your product*

WWW.MARSGAMING.EU